gSimplex

UL, ULC, CSFM Listed; FM Approved; MEA (NYC) Acceptance*

Features

TrueAlarm analog sensing provides:

- Digital transmission of analog sensor values via IDNet or MAPNET II two-wire communications
- For use with the following Simplex® products:
- 2 4007ES, 4010, 4010ES, 4100ES, and 4100U Series control panels; and 4008 Series control panels with reduced feature set (refer to data sheet S4008-0001 for details)
 2 4020, 4100, and 4120 Series control panels, Universal
- Transponders, and 2120 TrueAlarm CDTs equipped for MAPNET II operation

Fire alarm control panel provides:

- Peak value logging allowing accurate analysis of each sensor for individual sensitivity selection
- Sensitivity monitoring satisfying NFPA 72 sensitivity testing requirements; automatic individual sensor calibration check verifies sensor integrity
- Automatic environmental compensation, multi-stage alarm operation, and display of sensitivity directly in percent per foot
- Ability to display and print detailed sensor information in plain English language

Photoelectric smoke sensors provide:

Seven levels of sensitivity from 0.2% to 3.7% (refer to additional information on page 3)

Heat sensors provide:

- Three fixed temperature sensing thresholds: 135° F, 155° F and 190° F
- Rate-of-rise temperature sensing
- ² Utility temperature sensing
- Listed to UL 521 and ULC-S530

General features:

- 2 Operation is for ceiling or wall mounting
- Listed to UL 268 and ULC-S529
- Icouvered smoke sensor design enhances smoke capture by directing flow to chamber; entrance areas are minimally visible when ceiling mounted
- Designed for EMI compatibility
- Magnetic test feature is provided
- Different bases are available to support a supervised or unsupervised output relay, and/or a remote LED alarm indicator

Additional base reference:

- P For isolator bases, refer to data sheet S4098-0025
- P For sounder bases, refer to data sheet S4098-0028
- For photo/heat sensors, refer to data sheet S4098-0024 (single address) and S4098-0033 (dual address)

* These products have been approved by the California State Fire Marshal (CSFM) pursuant to Section 13144.1 of the California Health and Safety Code. See CSFM Listings 7272-0026:218, 7271-0026:231, 7270-0026:216, and 7300-0026:217 for allowable values and/or conditions concerning material presented in this document. Accepted for use – City of New York Department of Buildings – MEA35-93E. Additional listings may be applicable, contact your local Simplex product supplier for the latest status. Listings and approvals under Simplex Time Recorder Co. are the property of Tyco Fire Protection Products.



TrueAlarm Analog Sensors - Photoelectric

and Heat: Standard Bases and Accessories

4098-9714 TrueAlarm Photoelectric Sensor Mounted in Base

Description

Digital Communication of Analog Sensing. TrueAlarm analog sensors provide an analog measurement digitally communicated to the host control panel using Simplex addressable communications. At the control panel, the data is analyzed and an average value is determined and stored. An alarm or other abnormal condition is determined by comparing the sensor's present value against its average value and time.

Intelligent Data Evaluation. Monitoring each sensor's average value provides a continuously shifting reference point. This software filtering process compensates for environmental factors (dust, dirt, etc.) and component aging, providing an accurate reference for evaluating new activity. With this filtering, there is a significant reduction in the probability of false or nuisance alarms caused by shifts in sensitivity, either up or down.

Control Panel Selection. Peak activity per sensor is stored to assist in evaluating specific locations. The alarm set point for each TrueAlarm sensor is determined at the host control panel, selectable as more or less sensitive as the individual application requires.

Timed/Multi-Stage Selection. Sensor alarm set points can be programmed for timed automatic sensitivity selection (such as more sensitive at night, less sensitive during day). Control panel programming can also provide multi-stage operation per sensor. For example, a 0.2% level may cause a warning to prompt investigation while a 2.5% level may initiate an alarm.

Sensor Alarm and Trouble LED Indication. Each sensor base's LED pulses to indicate communications with the panel. If the control panel determines a sensor is in alarm, or is dirty or has some other type of trouble, the details are annunciated at the control panel and that sensor base's LED will be turned on steadily. During a system alarm, the control panel will control the LEDs such that an LED indicating a trouble will return to pulsing to help identify the alarmed sensors.

TrueAlarm Analog Sensing

TrueAlarm Sensor Bases and Accessories

Sensor Base Features

Base mounted address selection:

- Address remains with its programmed location
- Accessible from front (DIP switch under sensor)

General features:

- Automatic identification provides default sensitivity when substituting sensor types
- Integral red LED for power-on (pulsing), or alarm or trouble (steady on)
- Locking anti-tamper design mounts on standard outlet box

Department Magnetically operated functional test

Sensor Bases

4098-9792, Standard Sensor Base

4098-9789, Sensor Base with wired connections for:

2098-9808 Remote LED alarm indicator or 4098-9822 relay (relay is unsupervised and requires separate 24 VDC)

Supervised Relay Bases (not compatible with 2120 CDT): 2 4098-9791, 4-Wire Sensor Base, use with remote or

- locally mounted 2098-9737 relay, requires separate 24 VDC 4098-9780, 2-Wire Sensor Base, use with remote or
- locally mounted 4098-9860 relay, no separate power required
- Supervised relay operation is programmable and can be manually operated from control panel
- Includes wired connections for remote LED alarm indicator or 4098-9822 relay (relay is unsupervised and requires
- separate 24 VDC)

Sensor Base Options

2098-9737, Remote or local mount supervised relay:

 DPDT contacts for resistive/suppressed loads, power limited rating of 3 A @ 28 VDC; non-power limited rating of 3 A @ 120 VAC (requires external 24 VDC coil power)

4098-9860, Remote or local mount supervised relay:

SPDT dry contacts, power limited rating of 2 A @ 30 VDC, resistive; non-power limited rating of 0.5 A @ 125 VAC, resistive

4098-9822, LED Annunciation Relay:

- Activates when base LED is on steady, indicating local alarm or trouble
- DPDT contacts for resistive/suppressed loads, power limited rating of 2 A @ 28 VDC; non-power limited rating of 1/2 A @ 120 VAC, (requires external 24 VDC coil power)

4098-9832, Adapter plate:

- Required for surface or semi-flush mounting to 4" square electrical box and for surface mounting to 4" octagonal box
- Can be used for cosmetic retrofitting to existing 6-3/8" diameter base product

2098-9808, Remote red LED Alarm Indicator:

Mounts on single gang box (shown in illustration to right)



Description

TrueAlarm sensor bases contain integral addressable electronics that constantly monitor the status of the detachable photoelectric or heat sensors. Each sensor's output is digitized and transmitted to the system fire alarm control panel every four seconds.

Since TrueAlarm sensors use the same base, different sensor types can be easily interchanged to meet specific location requirements. This feature also allows intentional sensor substitution during building construction. When conditions are temporarily dusty, instead of covering the smoke sensors (causing them to be disabled), heat sensors may be installed without reprogramming the control panel. Although the control panel will indicate an incorrect sensor type, the heat sensor will operate at a default sensitivity providing heat detection for building protection at that location.

Mounting Reference

Electrical Box Requirements: (boxes are by others)

<u>Without relay in the box:</u> <u>4" oc</u>tagonal or 4" square, 1-1/2" deep; single gang, 2" deep

 $\underline{With\ relay\ in\ the\ box: 4"}$ octagonal or 4" square, 1-1/2" deep, with 1-1/2" extension ring







TrueAlarm Sensors

Features

Sealed against rear air flow entry Interchangeable mounting EMI/RFI shielded electronics Heat sensors:

Selectable rate compensated, fixed temperature sensing with or without rate-of-rise operation
 Rated spacing distance between sensors:

Fixed Temp. Setting	UL & ULC Spacing	FM Spacing, Either Fixed Temperature Setting			
135° F / 190° F* (57.2° C / 88° C)	60 ft x 60 ft (18.3 m)	20 ft x 20 ft (6.1 m) for fixed temperature only; RTI = Quick			
155° F40 ft x 40	50 ft x 50 ft (15.2 m) for fixed 155° F40 ft x 40 ft temperature with either rate-of-rise selection; RTI = Ultra				
(68° C)(12.2 m)		,			

*Note: 190° F (88° C) ratings apply only to the 4098-9734 sensor.

Smoke Sensors:

- Photoelectric technology sensing
- $\boxed{2}$ 360° smoke entry for optimum response
- Built-in insect screens

4098-9714 Photoelectric Sensor

TrueAlarm photoelectric sensors use a stable, pulsed infrared LED light source and a silicon photodiode receiver to provide consistent and accurate low power smoke sensing. Seven levels of sensitivity are available for each individual sensor, ranging from 0.2% to 3.7% per foot of smoke obscuration. Sensitivities of 0.2%, 0.5%, and 1% are for special applications in clean areas. Standard sensitivities are 1.5%, 2.0%, 2.5%, 3.0%, and 3.7%. Application type and sensitivity are selected and then monitored at the fire alarm control panel.*

The sensor head design provides 360° smoke entry for optimum response to smoke from any direction. Due to its photoelectric operation, air velocity is not normally a factor, except for impact on area smoke flow.



4098-9714 Photoelectric Sensor with Base

4098-9733 and 4098-9734 Heat Sensors

TrueAlarm heat sensors are self-restoring and provide rate compensated, fixed temperature sensing, selectable with or without rate-of-rise temperature sensing. Due to its small thermal mass, the sensor accurately and quickly measures the local temperature for analysis at the fire alarm control panel. Rate-of-rise temperature detection is selectable at the control panel for either 15° F (8.3° C) or 20° F (11.1° C) per minute. Fixed temperature sensing is independent of rate-of-rise sensing and programmable to operate at 135° F (57.2° C) or 155° F (68° C). The 4098-9734 sensor provides an additional 190° F (88° C) set point.

In a slow developing fire, the temperature may not increase rapidly enough to operate the rate-of-rise feature. However, an alarm will be initiated when the temperature reaches its rated fixed temperature setting.

TrueAlarm heat sensors can be programmed as a utility device to monitor for temperature extremes in the range from 32° F to 155° F (0° C to 68° C). This feature can provide freeze warnings or alert to HVAC system problems. Refer to specific panels for availability.



4098-9733 Heat Sensor with Base



4098-9734 High Temperature Heat Sensor with Base

<u>WARNING:</u> In most fires, hazardous levels of smoke and toxic gas can build up before a heat detection device would initiate an alarm. In cases where Life Safety is a factor, the use of smoke detection is highly recommended.

Application Reference

Sensor locations should be determined only after careful consideration of the physical layout and contents of the area to be protected. Refer to NFPA 72, the National Fire Alarm and Signaling Code. On smooth ceilings, smoke sensor spacing of 30 ft (9.1 m) may be used as a guide.*

* For detailed application information including sensitivity selection, refer to Installation Instructions 574-709.

TrueAlarm Analog Sensing Product Selection Chart

TrueAlarm Sensor Bases (for use with Sensors 4098-9714 and 4098-9733)

Model*	Color	Description		Compatibility		Mounting Requirements	
4098-9792	White					4" octagonal or 4" square box, 1-1/2"	
4098-9776	Black	Standard Sensor Base		No options		min. depth; or single gang box, 2"	
4098-9789	White	Sensor Base with connections for	.			4" octagonal or 4" square box Note: Box depth requirements depend on total wire count and	
4098-9789 IND	White	Remote LED Alarm Indicator or Unsupervised Relay	2098-9808 Remote Alarm Indicator or 4098-9822 Unsupervised Relay				
4098-9775	Black						
4098-9791**	White	Base with connections for LED 2098-9808 Remote		2098-9737 Supervised Remote Relay 2098-9808 Remote Alarm Indicator or 4098-9822 Unsupervised Relay	arm Indicator or		
		2-Wire Sensor Supervised Relay Base with connections for LED Indicator or Unsupervised Relay		4098-9860 Supervised Remote Relay		with the 2120 CDT	
4098-9780**	White			2098-9808 Remote Alarm Indicator or 4098-9822 Unsupervised Relay			
ueAlarm Sens	ors			19 ·			
Model*	Model*	Description		Compatibility		Mounting Requirements	
4098-9714 4098-9714 IND	White	Photoelectric Smoke Sensor		Bases 4098-9775, 4098-9776, 4098-9792, 4098-9789, 4098-9791, and 4098-9780			
4098-9774	Black					Refer to base requirements	
4098-9734	White	Heat Sensor High Temperature Heat Sensor			-		
ueAlarm Sens	or/Base Accesso	ries					
Model	Description	1		Compatibility		Mounting Requirements	
2098-9737	Supervised Relay, mounts remote or in base electrical box		For us	For use with 4098-97 <u>91 ba</u> se		Remote Mounting requires 4" octagonal or 4" square box, 1-1/2" minimum depth Base Mounting requires 4" octagonal box, 2- 1/8" deep with 1-1/2" extension ring	
4098-9860	Supervised Relay, mounts remote or in base electrical box Remote Red LED Alarm Indicator on single gang		For us	For use with 4098-9780 base			
2098-9808	stainless steel plate Unsupervised Relay, tracks base LED status; Note: Mounts only in base electrical box		9780	Bases 4098-9789, 4098-9791, and 4098- 9780 Bases 4098-9789, 4098-9791, and 4098- 9780		Single gang box, 1-1/2" minimum depth 4" octagonal box, 2-1/8" deep with 1-1/2" extension ring	
4098-9822							
4098-9832	Adapter Plate			Bases 4098-9792, 4098-9789, 4098-9791, and 4098-9780		or surface or semi-flush mounted 4" < and for surface mounted al box	

* Note: Model numbers ending in IND are assembled in India.

Specifications

Communications and Sensor Supervisory Power		IDNet or MAPNET II communications, auto-selected, 1 address per base			
Communications Connections		Screw terminals for in/out wiring, 18 to 14 AWG (0.82 mm ₂ to 2.08 mm ₂)			
Remote LED Alarm Indicator Current		1 mA typical, no impact to alarm current			
Remote LED Alarm Indicator and Relay Connections		Color coded wire leads, 18 AWG (0.82 mm ₂)			
UL Listed Operating Temperature Range		32° to 100° F (0° to 38° C)			
Operating Temperature	with 4098-9733 Heat Sensor	32° to 122° F (0° to 50° C)			
	with 4098-9714 Smoke Sensor	15° to 122° F (-9° to 50° C)			
	With 4098-9734 Heat Sensor	32° to 150° F (0° to 66° C)			
Storage Temperature Range		0° F to 140° F (-18° C to 60° C)			
Humidity Range		10 to 95% RH			
4098-9714 Smoke Sensor Air Velocity Rating		0-4000 ft/min (0-1220 m/min)			
Housing Color		Frost White or Black			
4098-9791 Base With Supervised	Remote Relay 2098-9737 (see page 2 for	or contact ratings)			
Externally Supplied Relay Coil Voltage		18-32 VDC (nominal 24 VDC)			
Supervisory Current		270 🗈 A, from 24 VDC supply			
Alarm Current with 2098-9737 Relay		28 mA, from 24 VDC supply			
4098-9780 Base With Supervised	Remote Relay 4098-9860 (see page 2 for	or contact ratings)			
Power		Supplied from communications			
4098-9822 Unsupervised Relay, F	Requirements for Bases 4098-9789. 4098	- 3-9791, and 4098-9780 (see page 2 for contact ratings)			
Externally Supplied Relay Coil Voltage		18-32 VDC (nominal 24 VDC)			
Supervisory Current		Supplied from communications			
Alarm Current		13 mA from separate 24 VDC supply			

SIMPLEX, and the product names listed in this material are marks and/or registered marks. Unauthorized use is strictly prohibited. NFPA 72 and National Fire Alarm Code are registered trademarks of the National Fire Protection Association (NFPA).



Westminster, MA • 01441-0001 • USA www.simplex-fire.com

© 2017 Johnson Controls. All rights reserved. All specifications and other information shown were current as of document revision date and are subject to change without notice.